



Instruction Booklet 使用說明



800W TOURMALINE CERAMIC IONIC HOT AIR STYLER

800 瓦特 電氣石陶瓷負離子熱風梳

VSAS80PIH



沙宣800瓦特電氣石陶瓷負離子熱風梳

您最新擁有的這款熱風梳備有三個配件，每一個配件都是讓您即使在家也能創造出髮廊效果的不可缺少的工具。

Airstyle 800是為您創造出吹乾效果和所有最潮流髮型的理想的工具。

它的800W風力和二段熱力/風速設定讓您無論在乾或濕髮(及任何一種髮質)都能夠使用。

重要安全指示

當使用電器時，尤其有小童在場，應小心及遵守以下安全指示：

使用前請細閱使用說明 電器應遠離水源

安全預防措施

警告：包裝或產品上使用的膠袋可能有危險，請擺放在嬰兒及兒童拿不到的位置。請勿於嬰兒床、睡床、嬰兒車或兒童遊樂園內使用。膠袋的薄層可能會堵塞鼻子及口腔，阻礙呼吸。此膠袋不是玩具。

警告：不要在盛水的浴缸、淋浴缸、洗臉盆或其他器皿附近使用本器具。

- 當風筒在浴室使用後，應立即拔除插頭，因為風筒接近水會導致危險，即使開關已關掉。為提供額外的安全性保護，建議閣下在提供浴室電源的電路中安置不超過30毫安培(mA)的漏電斷路器(RCD)；如有疑問，請向負責安裝的電機工程師查詢。
- 切勿把電器放入或掉進水或其他液體中。
- 如果電源線損壞，為了避免危險，必須由製造商、其維修部或類似部門的專業人員更換。
- 切勿堵塞電器的入風口，及放在柔軟表面上如床或梳化，因有機會堵塞入風口。請避免入風口受纖維、頭髮等碎屑堵塞。這個產品已配備了溫度斷路器。如果設備過熱，它會自動關閉或停止加熱。如果發生這種情況，請把開關關閉及拔去電源，讓產品冷卻10分鐘。再次使用前，請確保沒有任何其他污垢或頭髮在後方過濾網上。插上插頭和開機。如果它再次過熱，應立即停止使用，關掉電源並拔下插頭。交回沙宣服務中心檢查及維修。
- 若電器曾跌落地或有任何不妥，請馬上停止使用。
- 切勿將已接上電源或開啟的電器置之不理。
- 如若在使用中有任何不妥，請馬上拔去插頭。
- 請不要使用非本產品提供的任何配件。
- 每次用完後或清潔前請先拔去插頭。
- 切勿將電器發熱的部份碰到身體，尤其是眼睛、耳朵、面部和頸部。
- 本產品不該讓有智障，殘障，感官有缺陷或缺乏使用電器經驗與常識的人（包括兒童）單獨使用，而應由有經驗及常識之監管人監察及指導下使用此產品。小孩子應被監管以保證他們不會將此產品當成玩具。
- 待電器冷卻之後才收藏。
- 為避免損壞電源線，收藏時切勿將電源線纏繞在電器上並確保其不被拉扯、扭曲或屈折。

裝嵌及卸除配件

將刷梳配件裝上機身並確保兩者的軌道正確，然後將兩者按緊直到聽到卡嗒聲。

使用說明

此熱風梳備有三項設定：0 (關機)，I (低熱力) II (高熱力) 及* (冷風)。纖細髮質使用低熱力設定最為理想，而高熱力設定則適合較粗的髮質。

使用冷風設定有助您塑造持久固定的造型。

此熱風梳在乾爽或濕潤的頭髮上均適用，使用前請完全理順秀髮。利用髮夾分隔好頭髮，以便您能每次處理一髮束。首先為底層秀髮造型，每個髮束應該以最多兩厘米寬為佳，並盡量分佈平均。將熱風梳沿著髮束，由髮根慢慢向下拉至髮尾，然後取一撮髮束，以這個直徑38毫米的熱風梳髮捲將它捲曲。

直徑38毫米電氣石陶瓷塗層熱捲梳

令梳理頭髮時完美地順滑，更能呵護您的秀髮。這個同時兼備風筒及刷梳的組合令您對風乾秀髮出現革命性改變。沙宣推薦的這個理想直徑，不單令梳理頭髮時更順滑，同時在沒有令頭髮纏結的情況下增加髮型的立體感，更名為柔軟秀髮帶來最佳的風乾效果。

由機身產生的熱空氣加熱熱捲梳的金屬髮捲，熱力因而被直接地分佈至您的秀髮，令它變得柔軟和光滑。

散風梳

將散風梳置於頭髮下方，盡量靠近髮根，再向髮尾滑動。這動作可為您塑造完美髮型。

電氣石陶瓷塗層直髮梳

透氣刷的人體工程學調直刷頭使它特別容易使用：只需由髮根至髮尖拉一下，秀髮就能同時吹乾並且拉直！直髮梳上的一排齒梳讓您梳理頭髮更事半功倍，大大增加效率和速度。它的電氣石陶瓷塗層提供完美的順滑梳理效果，並且保證頭髮調直無誤，同時呵護您的秀髮。

拉力控制系統的四級設定：1.波浪鬆髮 2.普通鬆髮 3.大鬆髮 4.蓬鬆鬆髮

鬆髮有四個基礎的型態(波浪鬆髮、普通鬆髮、大鬆髮、蓬鬆鬆髮)。其經驗促使我們創作出拉力控制系統，為沙宣刷梳帶來了無與倫比的性能。這個專利技術可配合內置力度，適合拉直不同程度的鬆髮，讓您在風乾秀髮的同時，無須另外梳理或拉順秀髮！

開始認識您的800瓦特電氣石陶瓷負離子熱風梳



電氣石陶瓷科技

電氣石陶瓷科技是將壓碎的電氣晶石，注入陶瓷之中的新科技。電氣石釋出負離子，大大縮短乾髮時間及減少靜電的形成。陶瓷熱板釋出遠紅外線，有助熱力快捷均勻地分布，減少熱力對秀髮的傷害，溫和乾髮，效果卓越，提供更快捷健康的乾髮造型，更亮麗貼服的效果。

負離子科技

現代生活中很多情形都會導致靜電積聚於頭髮，例如空調、接觸人造纖維，以及空氣污染等等。甚至梳頭及用毛巾抹乾頭髮都可能令頭髮上的靜電增加。靜電會導致髮絲相互排斥，令頭髮無法順滑貼服，並顯得蓬亂不堪，看上去顯得缺乏光澤。靜電積聚過多會令頭髮蓬亂不已，難以進行造型。本設備的內置離子產生器可透過釋放負離子，減少秀髮上的靜電，從而減少蓬亂髮絲，令秀髮散發絲質順滑和天然光澤。

使用者保養指示

您的熱風梳基本上毋須特別保養，毋須加潤滑油。為保持熱風梳操

作正常，必須保持熱風梳清潔。堵塞的入風口會引致熱風梳過熱。如需要清潔，拔去插頭，用小刷或吸塵機的刷掃去入風口的塵垢纖維。只可用微濕布抹淨熱風梳外殼。若熱風梳過熱，自動安全裝置會自動關掉熱風梳以避免損壞或引致損傷。若熱風梳關機，拔去插頭，再使用前讓熱風梳冷卻10至15分鐘。請確保通風口並無碎屑堵塞。

警告

切勿拉扯、扭曲、或嚴重摺曲電源線。切勿將電源線圍繞熱風梳。這會引致電源線連接口斷裂並引致短路。請經常檢查電源線有否損壞。若電器損壞或間歇性關機，請立即停止使用。若電源線或熱風梳損壞或不正常操作，請交到沙宣顧客服務中心檢查及維修。切勿自行維修電器。

收存指示

非使用熱風梳時，拔去插頭並收存在安全、乾爽、遠離兒童的地方。切勿將電源線圍繞熱風梳。

電線系統

總電線的顏色根據其性質而定：

藍色代表中線
啡色代表火線

由於電器的總電線顏色和插頭的電路接頭顏色可能不相符，故如要拆除插頭必須依照以下重新裝配操作說明：

- 藍色的電線應和電路接頭“N”接駁。
- 啡色的電線應和電路接頭“L”接駁。
- 切勿將以上任何一條電線駁在電路接頭的地線“E”或⊕插頭上。

此電線使用十三安培電插頭時，請採用十三安培的保險絲。若使用其他電插頭，請採用十三安培保險絲。

兩年保養期限

在您購買日期起兩年內，並在正常情況下，如產品的品質或零件有任何不妥善之處，沙宣顧客服務中心將會為您免費提供維修或換貨服務。如需獲得此保用服務，只需保留正本收據，倘若產品於保養期內有任何問題，可蒞臨您所在地區的顧客服務中心處理。注意：是項保養不包括一切因錯誤使用、不依指示處理產品及意外損毀、遺失零件及經自行改造的產品。

保用期之後

請致電使用說明中所列出的您所在地區的沙宣顧客服務中心，查詢維修服務詳情，或是電郵至email_asia@conair.com，附上您的名字，電話號碼和電郵地址，還有產品不妥善之詳情。

如欲了解更多，請登入



VS SASSOON SERVICE CENTRE

Manufacturer: Conair Far East Ltd
Address: 35/F., Standard Chartered Tower, Millennium City,
388 Kwun Tong Road, Kwun Tong, Kowloon, Hong Kong.
Tel: (852) 2751 4604

沙宣顧客服務中心

製造商：美康雅遠東有限公司
地址：香港九龍觀塘觀塘道388號創紀之城渣打中心35樓
電話：(852) 2751 4604

www.toolsofsassoon.com

SOLE DISTRIBUTED BY:

經銷商:

Malaysia 馬來西亞
Innovest Marketing Sdn. Bhd.
Lot 2208, Jalan Kusta, Kampung Jaya Industrial Area, 4700 Sungai Buloh,
Selangor D.E. Malaysia
Tel: 603 6141 3598

Singapore 新加坡
Massmark International Pte Ltd
629 Aljunied Road #06-18
Cititech Industrial Building Singapore 389838
Tel. No.: 65 6747 1102 Fax No.: 65 6747 8997

Thailand 泰國
Central Trading Co., Ltd. (Central Marketing Group)
3388/25-37, 51-53 and 82-85 Sirinrat Building 8-11,
15 and 23rd Floor Rama 4 Rd.,
Klong-ton, Klong-toey, Bangkok 10110, Thailand
Tel : (66) 2 229 7000 Fax : (66) 2 367 5516

Indonesia 印尼
CV. Paten
Komplek Puri Deltamas Blok C No. 28
Jl. Bandengan Selatan 43,
Jakarta Utara 14450 - Indonesia
Phone: (021) - 6693420, 6693478
Fax: (021) - 6693511

Vidal Sassoon and related logos are trademarks of
The Procter & Gamble Company used under license by Conair Corporation.
維達沙宣及其有關標誌乃寶潔有限公司擁有，授權予美商美康雅公司使用。

VSAS80PIH

IB-11/166C

CONTINENTAL CONAIR LIMITED CHINA CREATIVE DEPARTMENT

Date	3/20/2015
Customer	VS-HK
Model No.	VSAS80PIH
Description	IB
Job No.	15VS018
Reference No.	IB-11/166C
Revision No.	1
Color	1C+1C(Black)
Open Size	552mm(W) X 214mm(H)
Folded Size	92mm(W) X 214mm(H)
Material	80gsm Artpaper
Prepared by	Betty bai
Approved by	Jimmy Ng/Ringo Tam
Vendor	Silverplan
Supplier	

折疊方法
Folding method:
12 pages (6 x 2)



VS SASSOON 800W TOURMALINE CERAMIC IONIC HOT AIR STYLER

Your new hot-air brush comes with 3 accessories, each one indispensable for reproducing your hair stylist's creations at home.

Airstyle 800 is the ideal tool for creating your blow-dry look and all the trendiest styles.

Its 800W airflow and two heat / speed setting mean you can use it on damp as well as dry hair (and on any type of hair).

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

SAFETY PRECAUTIONS

WARNING: The polyethylene bags over the product or its packaging may be dangerous. Keep these bags out of the reach of babies and children. Never use them in cribs, children's beds, pushchairs or playpens. The thin film may cling to the nose and mouth and prevent breathing. A bag is not a toy.



WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.



1. If you are using the unit in a bathroom, unplug it after you have finished using it. Using the unit close to a source of water can, in fact, be dangerous, even if the unit is switched off. To ensure additional protection, have installed in your bathroom a residual current device (RCD) with a nominal trip current no higher than 30 mA. Ask your electrical fitter for advice.
2. Never immerse the unit in water or any other liquid.
3. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
4. When using the unit, make sure the unit's air vent is not blocked. Make sure there is no hair or any other dirt obstructing the unit's rear filter.
5. This unit has been equipped with a temperature cut-out. If the unit overheats, it will shut off automatically or will stop heating. If this happens, slide the switch on the unit's handle into the OFF position, unplug the unit and allow it to cool for 10 minutes. BEFORE using it again, make sure there is no hair or any other dirt in the unit's rear filter. Plug the unit in and switch it on. If it overheats again, stop using it immediately, switch it off and unplug it. Return the unit to the VS SASSOON service centre.
6. Do not use the unit if it has fallen or if it appears to be damaged.
7. Do not leave the unit unattended when it is plugged in or switched on.
8. Unplug the unit immediately if you have problems when

using it.

9. Do not use any accessories other than those recommended by manufacturer.
10. Unplug the unit after each use and before cleaning it.
11. Avoid any contact between the unit's hot surfaces and your skin, in particular, your ears, eyes, face and neck.
12. This unit is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or by persons who lack experience or knowledge, unless they are supervised or have been given instructions beforehand on the use of the unit by a person responsible for their safety. Children should be supervised to make sure they do not treat the unit like a toy.
13. Allow the unit to cool before storing.
14. To prevent damage to the cord, do not wrap it around the unit and ensure it is stored without twisting or folding it.

FITTING AND REMOVING THE ATTACHMENTS

Fit the brushes onto the body of the unit by lining up the guides on the two parts and then press the two together until you hear a click.

INSTRUCTION FOR USE

The brush has 3 settings: 0 (off), I (low), II (high) and ★ (cool). The low setting is ideal for fine hair, the high setting for thicker hair.

The cool position lets you to fix the styling for really long-lasting effects.

Use your hot-air brush on pre-dried, slightly damp hair that is completely tangle free.

Use clips to separate hair so that you can work on one section at a time. Start with the sections underneath. Sections should be a maximum of 2cm wide and as even as possible. Always work from the roots to the tips and slide the brush slowly down the length of the section. Then take small sections of the hair, and curl it with the 38mm barrel of the hot air brush.

THE 38MM DIA TOURMALINE CERAMIC COATED THERMAL BRUSH

For perfect glide and to offer your hair better protection.

The combination 'brush/hair dryer' will revolutionise your blow drying!

This ideal diameter, recommended by VS SASSOON, creates a smooth movement and adds body to your hair without tangling it and for the best blow-dry results for hair full of softness.

The hot air of the unit heats the metal barrel of the attachment. The heat is thus distributed directly over your hair making it soft and smooth.

THE VENT BRUSH

Place the brush under hair, close to the roots. Slide it down to hair ends. This will give perfect shape to your hair style.

THE TOURMALINE CERAMIC COATED STRAIGHTENING COMB

The ergonomic straightening head of airbrush makes it especially easy to use: hair dried and straightened from roots to tips in just one stroke!

The one row of teeth let you straighten twice in just one stroke for greater efficiency and speed. The Tourmaline Ceramic coating provides perfect glide through your hair and guarantees perfect straightening, while completely respecting the hair.

Tensio Control System® 4 settings: 1. waves, 2. loose curls, 3. tight curls, 4. very tight curls

There are 4 fundamental types of curls (waves, loose curls, tight curls, very tight curls). Its experience today brings to VS SASSOON brushing an unequalled performance thanks to the Tensio Control System®. This patented technology can adapt to every type of curl, providing the right tension for perfect straightening: no more tugging and tearing hair during laborious blow-drying!

GET TO KNOW YOUR 800W TOURMALINE CERAMIC IONIC HOT AIR STYLER



TOURMALINE CERAMIC TECHNOLOGY

The Tourmaline Ceramic Technology features crushed tourmaline gem stone crystals infused with ceramic. Tourmaline emits negative ions which dramatically reduce drying time and static electricity. Ceramic emit far infrared heat providing a gentle, even heat that is less damaging. The results are unsurpassed; faster, healthier drying with shiny, smooth results.

IONIC TECHNOLOGY

Many aspects of modern living, including air conditioning, contact with man-made fibres and air pollution contribute to a build-up of static electricity in the hair. Even brushing and towel drying the hair, can increase these levels causing the surface of the cuticle to become rough. Consequently, hair may have a dull appearance. High levels of static charge cause hair to become "fly-away" and difficult to style. The ion generator in this dryer produces a stream of negative ions which act to neutralise the static charge, smoothing the scales on the cuticle for shiny, smooth and manageable hair so you can achieve your desired style easily.

USER MAINTENANCE

Your hot air styler is virtually maintenance-free. No lubrication is needed. For proper operating performance, the hot air styler must be kept clean. Blocked or clogged air intake vents will cause the hot air styler to overheat. When cleaning is needed, unplug the cord, and clean dust and lint from air intake openings with a small brush or the brush attachment of a vacuum cleaner. The outer surface of the hot air styler should be wiped clean with a damp cloth only.

If overheating occurs, an automatic safety device will shut the hot air styler or the heat off to prevent damage or personal injury. If the unit or the heat cycles off, unplug the cord and allow the hot air styler to cool for 10 to 15 minutes before restarting. Make sure the air vents are clean.

CAUTION

Never allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the hot air styler. Damage will occur at the high flex point of entry into the hot air styler, causing it to rupture and short. Inspect the cord frequently for damage. Stop use immediately if damage is visible or unit stops or operates intermittently.

STORAGE

When not in use, your appliance should be disconnected and stored in a safe, dry location out of reach of children. Do not jerk or strain cord at plug connections. Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

WIRING INSTRUCTIONS

The wires in the mains lead are coloured in accordance with the following code:

BLUE = NETURAL
BROWN = LIVE

As the colours of the wire in the mains lead of this appliance may not correspond with the colour markings identifying the terminals on your plug proceed as follows:

- The wire which is coloured BLUE must be connected to the terminal which is marked with the letter "N" .
- The wire which is coloured BROWN must be connected to the terminal which is marked with the letter "L" .
- Neither the BLUE nor BROWN wires should be connected to the terminal which is marked with the letter E or the ⊕ symbol.

With this appliance, if a 13 amp plug is used a 13 amp fuse should be fitted. If any other type of plug is used a 13 amp fuse must be fitted either in the plug or at the distribution board.

LIMITED TWO YEAR WARRANTY

This styler can be repaired or replaced free of charge for 2 years from the date of purchase if the styler is defective in workmanship or materials. This warranty is no longer valid in case of alteration or repair by any unauthorised persons. To obtain service under this warranty, please keep the original purchase receipt for warranty service, and you can bring the styler to our customer service center for repair during the warranty period.

OUT OF GUARANTEE

Call VS Sassoon Service Centre in your region as listed in this Instruction Booklet for details of repair service. Or email to us at email_asia@conair.com with your name, contact telephone number and email address and details of the fault.

For more information, please visit

